

**ATLAS COPCO**



Atlas Copco QST Tool Test



Atlas Copco ETD-S9-200-13  
PF3109 Graphing with Silver  
RBU Tensor 10M Tool Cable



Atlas Copco ETV-ST61-50-10  
PF4000 with Silver RBU  
TensorST 5M Tool Cable



Atlas Copco Test Area

**Tools**

462 Series	Tensor S Series: 4, 7, 9	DS Series: 4, 7, 9	QST Series:
422 Series	Configuration Family	Configuration Family	34, 42, 50,
482 Series	(ETV, ETD, ETP, ETF, ETC, ETO, HAD)	(ETV, ETD, ETP)	62, 80, 90, 95
STB Series:	Tensor ST Series: 31, 32, 61, 81, 101	SL Series: 21	ETX Series:
32, 33, 36	Configuration Family	Configuration Family	42, 50, 62, 72, 90
	(ETV, ETD, ETP, ETF, ETC, ETO, HAD)	(ETV, ETD, ETP)	
QMR Series:	QMX Series:	STR Series: 21,61	
42, 55, 62, 90	42, 50, 62, 80	Configuration Family	
		(ETV, ETD, ETP)	

**Controller Repair**

CSS91	
Power Focus 2101	Power Focus SL/DL
Power Focus 3000/3100	Power Mac TC52/54
Power Focus 4000	Power Mac 4000

**Controllers / Signal Conditioners**

ACTA 3000  
ACTA 4000

**Transducers/Torque Analyzers**

IRTT     IRTT-B  
SRTT     SRTT-B

**Torque Wrenches**

STWrench



Atlas Calibration &  
Test Equipment



Atlas Copco QMX50-15RT  
Power Mac TC52 Stand Alone  
10M QMX Tool Cable



Atlas Copco ETD-D37-30-10  
Compact DS7 Controller  
DS 10M Tool Cable



Atlas Copco Calibration  
Test Equipment



## COOPER / CLECO

### TOOL SERIES

- 17EA •47EA •67EA •17EP •47EP
- 17ES •47ES •67ES •B17ES •B17EA
- 47EC •47ET •17B •47B •TCM
- 2 •14 •8 •88 •35
- 5 •24 •34 •45 •55
- 75 •64 •PH •PTH •STH
- 11 •120 •135 •136DL •14

### CONTROLLERS

- TMEB
- TMEM
- TME
- TMEC
- TMEI
- ITD- Cooper
- TorkTrak

### CABLES

- All Cables

### TESTING EQUIPMENT


- P2 & P-15 Torque Analyzers
- TVP-100 Series Torque Verifier
- TA4 Torque Analyzer
- DA Dial Indicating Torque Wrenches



Cooper Test Area



Cooper Tool Testing



Cleco Tool Testing

### CLECO

Cordless Livewire Tools Series: 17, 47  
EA Series: 18, 48, 67  
ES Series: 18, 48, 67  
EP Series: 18, 48  
ET Series: 48  
EC Series: 48

#### PUSH TO START SERIES

EP and ES Series: 18

#### CURRENT CONTROLLED

CA, CP, CC and CS Series: 18, 48

#### FIXTURED INTELLIGENT SPINDLE

Sizes 1, 2, 3, 4

#### FIXTURED SPINDLE

EMT Series: 600, 800, 1200

EMT Series (Old/Tork-Trak): 40, 80, 200, 400, 550

TT Series (Old/Tork-Trak): 160, 300

B Series: 1, 2, 3



**STANLEY**

**TOOLS**

QPM E Series tools: 02, 12, 23, 33, 34, 35, 44, 45, 55

QPM EA Series Tools: 22, 23, 33, 34

QPM EB Series Tools: 12, 22, 33, 44, 55

QPM EC Series Tools: 02, 12, 22, 33, 34, 44



Stanley Family of Controllers

**TOOL SERIES**

- A30 • A32 • A33 • A40 • A50
- F50 • D30 • F3 • PE • A30M
- A3MFCT • A32MFOCT • A40M • E20 • E24
- E30 • E40 • EF • M30 • M40
- W30 • W40 • QPM
- Pistol Tools E02pb-e34pb
- Lever Tools E12lb - E55lb And Ea23lb - Ea34lb
- Lever Tools E12la - E55la And Ea23la - Ea34la
- Crowfoot Tools E12lc - E45lc And Ea23lc - Ea34lc
- Tubenut Tools E12lt - E44lt And Ea23lt - Ea34lt
- Hold & Drive Tools E34lh- E55lh
- Straight Motors E12lp, E23mb - E55mb, and E23mbf - E55mb5f
- Offset Motors E23mdf - E55md3f
- Angle Motors E33ma18 - E55ma32 and E33ma18f - E55ma32f



Stanley E33 Nutrunner

**CONTROLLERS**

- Alpha
- Gamma
- Delta
- Sigma
- Kappa
- Omega
- T8000
- Beta Tech

**Controller Repair**

- QPM-Alpha
- Delta GEN II/III
- Gen IV Alpha/Theta

**CABLES**

- All Cables

**TESTING EQUIPMENT**

- All Transducers



**AIR TOOLS**

A Series: 30, 32, 33, 40, 50

AA Series: 23, 33

F Series: 30, 32, 33, 40, 50

AH Series: 30, 40

AM Series: 30, 40, 60

AP Series: 30, 40, 60, 64

AT Series: 40, 60, 64, 84, 86

MAP Series: 40

PA Series: 2, 3, 4

